


TROPITONE®



CANTILEVER UMBRELLA

TROPITONE®

CANTILEVER UMBRELLA



ASSEMBLY INSTRUCTIONS

Congratulations on the purchase of your Tropitone® Cantilever Umbrella. Please read all instructions carefully before assembling and using this product. Keep this guide for future reference.

CAUTION!

Do not try to lift or flip umbrella components with only one person. Components and assembled umbrella may be heavy and awkward to handle, and may result in injury to persons or damage to property if not lifted properly.

ASSEMBLED UMBRELLA IS HEAVY. ASSEMBLE AT PLACE OF USE.

✓ Check that all hardware and components are provided before you start assembly.

REQUIRED TOOLS


Hex Head Wrench (included) 

Safety Glasses

COMPONENTS

- (1) Base Stand
- (4) Base Weight (429# total)
- (1) Lower Pole
- (1) Upper Pole
- (1) Umbrella Top Frame Assembly with cover
- (1) Crank Handle

HARDWARE

- (2) Hex Head Cap 
- (2) 3/4" Lock Washer 
- (1) Threaded Stud 
- (4) Hex Head Screw 
- (4) 1 1/4" Washer 

ASSEMBLY STEPS

1. Place Base Stand in the location you will use the fully assembled Cantilever Umbrella.

Place the four (4) Base Weights in (1) Base Stand using the stainless steel handles to lift the Base Weights.

TROPITONE®

CANTILEVER UMBRELLA




ASSEMBLY STEPS (CONTINUED)


2. To avoid damage to the finish of your Cantilever Umbrella Poles, prepare a smooth, non-scratch work surface (shipping carton, a tarp or pool towels can be used).

Place the Lower Pole on its side on your prepared work surface. Align the open end of the Upper Pole with the corner bracket of the Lower Pole so that the Upper Hook on the Upper Pole is facing upward.


Insert the Upper Pole into the Lower Pole Corner Bracket aligning the assembly holes in both poles. Insert the Threaded Stud through the assembly holes and install a $\frac{3}{4}$ " Lock Washer and Hex Head Cap on either side of the Threaded Stud. Fully tighten both sides using the Hex Head Wrench.




3. Using (2) persons, lift the Upper Pole and Lower Pole assembly to the vertical position. Place the square plate at the lower end of the Lower Pole on to the assembly of the Base Stand. Orient the Upper Pole with Upper Hook so that the Assembly is facing away from the Base Weights. Align holes of the square plate with the threaded holes on the Base Stand. Using the Hex Head Wrench, install (4) Hex Head Screws and (4) $1 \frac{1}{4}$ " Washers. Fully tighten.



4. On the top of the Umbrella Top Frame Assembly with Cover, locate the two (2) double-screw bolts. Using (2) persons, lift the Umbrella Top Frame Assembly with Cover upwards and insert the two (2) double-screw bolts in to the slot on the Upper Hook. Ensure that the Assembly is firmly seated in the Upper Hook Slot. Tighten the screws to secure the Assembly to the Upper Arm.



5. To assemble the lower and upper halves of the Umbrella Cable, locate the two ends of the Cable. Each of the (2) Cable ends has an oval Cable Protector attached. Place the (2) ends of the Cable Protector together and twist to screw the two halves together.



TROPITONE®

ASSEMBLY STEPS (CONTINUED)

6. Insert Crank Handle in to the opening in the front of the Crank Box. Press firmly to engage the Crank Handle. To open the Cantilever Umbrella, slowly turn the Crank Handle clockwise. To close the umbrella, slowly turn the Crank Handle counter clockwise.
7. To rotate the Cantilever Umbrella, locate the Pin and Chain assembly at the lower end of the Lower Pole. Pull the Pin out and slowly rotate the Pole Assembly until you see the next insertion hole in the Base Stand. Insert the Pin in to the insertion hole to secure the umbrella in the desired position.

CARE INSTRUCTIONS

For care and cleaning instructions, refer to the Tropitone® Care, Maintenance, Safety & Warranty Information guide included with your furniture and available at www.tropitone.com/warranty.

Additional care information, "How To" videos and assembly instructions for Tropitone Outdoor Furniture and Basta Sole shade products are also available on our website.

CUSTOMER SERVICE

If you have difficulty understanding any of the instructions and need assistance while assembling your Cantilever Umbrella, please call Tropitone's Customer Service Center at 949.951.2010.

Tropitone Furniture Co., Inc.
5 Marconi
Irvine, California 92618
949 951 2010
www.tropitone.com

Warranty

For our current Warranty and product care information, please visit www.tropitone.com/warranty
Part # R9T00049
©2019 Tropitone Furniture Co., Inc.
07/19